



GRAB & GO USER MANUAL































WARNING!

- Failure to comply with these instructions may lead to serious injury or death.
- Grab & Go Maximum load is 30 lbs; 14 kg
- Do not carry children in the bag.
- Do not carry animals in the bag.
- Riding with extra weight may alter the riding characteristics of your bicycle, decrease stability, and increase braking distances.
- Make sure the bike is stable before adding extra weight.
- Make sure that the loading of the bag does not interfer with the rotation of the handlebars.
- Check that any bag parts and fabric do not interfere with the bike's **moving parts** such as cables, wheels and brakes.
- Make sure the bag is properly and securely attached to the bike before moving.
- Make sure the bag is properly closed before moving.
- Regularly check straps and clips for signs of distress, and wear and tear. If straps, clips, or bag show signs of distress, order replacement bag/parts immediately. Do not use if parts are torn or damaged.
- Note that this bag does not constitute a barrier to acts of vandalism.